Note: The RED and RED/WHITE/RED STRIPE wires will not be used. CABINET SNUBBER GRD. GRD **SNUBBER** GRD. SPOT WELDER 0000000000 **900000000** 2-WHITE 1-BLACK PLG1 TD1 & TD2 NOWELD TD2 9-ORANGE **MILLER MPS** Connect to green/black stripe wire in cable. Connect the other end of this green/black stripe wire in the SOFT TOUCH box to terminal #13 (SVH) on the SOFT TOUCH TS7 sensor **HOOKUP** Disconnect this wire from terminal 11 on TD1. board. There will now be two wires in terminal #13 (SVH).