TECHNITRON T2050

SOFT TOUCH HOOKUP

Remove wire from PS terminal.

Connect that wire to RED/BLACK STRIPE.

Connect RED wire to terminal PS.

RED/BLACK STRIPE

RED

BLACK

ORANGE

WHITE

Set DIPswitch 3 (DP3) to the OPEN position. This is the second-stage mode needed to allow the electrodes to open if continuity is not detected.

Opening the foot switch when continuity is not detected will open the electrodes.